

Other Items Needed

for Installation of Railing Systems



Cordless Drill



Level



Tape Measure



3/8" Hex Driver Bit



#2 Square Drive Bit



Miter Saw
with Nonferrous blade



3/16" Drill Bit



Pencil



Safety Glasses